

Quick Disconnect UV Parts Guide

Quick Disconnect Quartz Sleeve Standard Assembly (QDCQSSTDA)

- 1 – QDGK2 QUICK DISCONNECT GASKET 2"
- 1 – QDCL2 QUICK DISCONNECT CLAMP 2"
- 1 – QDCAP1PVC QUICK DISCONNECT COMPRESSION CAP 1" PVC
- 2 – RCG1 RUBBER COMPRESSION GASKET 1"
- 1 – QSSTD QUARTZ SLEEVE STANDARD AMALGAM
- 1 – QDC316 QUICK DISCONNECT CONNECTOR 316SS

NOTE: QDGK2 & QDGK2
SOLD SEPARATELY

